



Smart Classroom Orientation





The AMX Control Panel

- Controlled by a wireless signal
- Which signal do you have IR (infra-red) or RF (radio frequency)?
- If the signal is obstructed...






Start by touching the touch panel

Press here to begin...





The Home Page Screen

Audio-Visual components are accessed
from this screen

Smart Classroom Equipment

Various designs




Various cabinet styles



Video Data Projector (VDP)

- Mounted from ceiling or mounted on table
- Projects laptop, VCR/TV, DVD, doc cam & AUX video
- VDP will TIME-OUT after 2 hours. Simply touch the TOUCH PANEL screen to reset the timer.




Doc Cam

- Permanently installed or added to room as “AUX”
- BACK light for transparencies
- Front light to display
- Zoom in & out
- Auto focus or in & out
- Other controls on unit



Satellite Cable TV



2 KYGN

4 KCNC

5 RES CH

6 KRMA

7 KMGH

8 KTVD

9 KUSA

10 KTFD

16 AMC

17 IFC

18 CH 54

19 CCD

20 MSCD

21 UCD

22 Natl Geo

23 CSPAN

24 CNN

25 Weather

26 CNBC

27 Discovery

28 History

29 ESPN

31 BBC


33 NASA



DVD


DVD menu

- No picture?
- Pioneer or Phillips?
- Is Progressive scan on?



Advanced menu

- DVD menu-scene selection
- Find the Chapter or Track
- Press Play or Enter



2 models of DVD players in Smart Classrooms

Phillips



- They both play DVD_{r±}
- The Phillips disk drawer is on the left
- The Pioneer disk drawer is in the middle

Pioneer



➤ When "Green" light is on, you will have audio but no video

✓ Hold button down until green light turns off




VCR Player

- ❑ Power must be on
- ❑ VCR acts as the cable TV receiver
- ❑ Channel up/down on VCR adjusts

TRACKING

- ❑ New classrooms do not have a VCR built into system




Laptop Output

Functions Keys:

Acer	Fn + F5
Apple	Must use adapter
Compaq	Fn + F4
DEC	Fn + F4
Dell	Fn + F8
Fijitsu	Fn + F10
Gateway	Fn + F3/F4
Hitachi	Fn + F7
HP	Fn + F4/F5
IBM	Fn + F7
NEC	Fn + F3
Panasonic	Fn + F3
Sharp	Fn + F5
Sony	Fn + F7
Toshiba	Fn + F5

- Laptop to projector
- VGA computer cable in room
- NO adapters for MACs
- PC audio cable provided




AUX Video Connection

- AUX is used for any connection that requires Stereo cables and a video cable
- DOC, DVD, VHS, Cameras
- Color coded cables provided: **Red** is right speaker, **white** is left speaker and **yellow** is video




CD & Cassette Players

CD Player



Cassette Player






- Return to “Home Page” to switch to another source or to “exit” the system

The Home page options

• You may switch from your power point presentation and push VHS or DVD to watch a video then return to PC and finish the power point where you left off


We have included our Help Desk extension on the Home page if you need assistance



Push the red **EXIT** to shut down system

The system has not shut down at this point

- It asks you if you are sure because if you came to this screen by accident you can push “NO” and return to the Home Page Screen
- When you are finished push “YES” and the projector will now turn off



The system is now shut down

- Please remember to always shut the system down before you leave your class
- Please allow the fan to shut off from the video data projector before you turn the system on again

PLEASE WAIT...

Projector is recycling
(about 1 minute)

Auraria Media Center

Provides a Full Range of Media Services

- Audio/Video Production
- Audio/Video equipment rental
- Video Conferencing: eLearning/Distance Education Services
- Transfer and Duplication Services
- Self Serve Media Lab
- Broadcast/Production Studios
- Campus TV
- Classroom Helpdesk/Classroom Support Tech Services
- Classroom Equipment Repair & Installation Services

Personal Training in Classroom

- If you wish to have personal training in your classroom call **6.2452** to schedule an appointment.
- We recommend to schedule the 15 minutes prior to the beginning of your class to have a technician meet with you in the room .
- Please bring your laptop with you to receive PC connection training.



Media Help Desk Assistance

- Please call **6.3342** when you are having difficulties with the media equipment
- A help desk technician will help you on the phone or dispatch a technician to your room as soon as possible
- If you get a recording, please leave a message that gives your bldg and room number, and phone number to return your call.



**AURARIA
MEDIA CENTER &
CLASSROOM SUPPORT
SERVICES**



Classroom Support Tech Hours

Monday-Thursdays 8am-10pm

Fridays 8am-5pm

Saturdays 8am-1pm



Audio/Visual Equipment Orders

To Reserve equipment:

- To order equipment call the classroom support equipment reservation line **6.2452**
- Order equipment at least one day prior to the day it is needed - “No same day orders”
- You will be required to pick up your equipment from the satellite nearest your classroom and return the equipment at the end of your class.

Equipment Satellites:

- **AR 299** - Arts bldg, West Classroom bldg, & Central bldg
- **SO 137** - South bldg, & Tech Ed bldg
- **NC 1808** - North Classroom bldg, P.E. Bldg & Science bldg
- **PL 109** - Plaza Building
- **KC 115** - King Center Building
- **AD P100K** - Admin, Seventh Street, Facilities Annex
- **SI 3078** - New & Renovated Science bldg



Our location is on the eastside entrance of the Auraria Library Building in the basement on the Auraria Campus at 1100 Lawrence Street or go to our website:

<http://mediacenter.ahec.edu/classroom.html>

To view the Video: [Introduction to Smart Classrooms](#)
or view or print this [Power Point Presentation](#)



Thank you!

**We hope this has helped you begin
the Spring 2011 Semester on the
Auraria Campus**